


Original version of operating instructions

Transportation | Assembly | Operation | Maintenance



Product line:	condensers R134a, R404a, R507,...
Series variant description:	Axial; for low capacities
Series:	GVM

www.guentner.de

Contents

1	Important basic information.....	5
1.1	Safety instructions.....	5
1.1.1	Observing operating instructions.....	5
1.2	Importance of the EN 378 series of standards – refrigeration systems and heat pumps – safety-related and environmental requirements.....	5
1.3	Responsibilities.....	5
1.3.1	Manufacturer's responsibilities.....	5
1.3.2	Responsibilities of the system's installer.....	6
1.3.3	Owner or operator responsibilities.....	6
1.4	Legal notes.....	7
1.5	Operating instructions.....	7
1.5.1	Scope.....	7
1.5.2	Set-up and other applicable documents.....	7
1.6	Conventions.....	8
1.6.1	Typographical conventions.....	8
1.6.2	List of abbreviations.....	8
1.7	Conventions for safety signs and notices.....	9
1.7.1	General safety signs and their meaning in these operating instructions.....	9
1.7.2	Warning signs and their meaning in these operating instructions.....	9
1.7.3	Prohibitory signs and their meaning in these operating instructions.....	10
1.7.4	Mandatory signs and their meaning in these operating instructions.....	10
2	Safety.....	12
2.1	Labelling on the unit:.....	12
2.1.1	Safety signs on the unit.....	12
2.1.2	Other signs and notes on the unit.....	13
2.2	Basic safety notices.....	13
2.2.1	How to act in an emergency.....	13
2.2.2	Personnel, care requirements.....	14
2.3	Proper intended use.....	15
2.3.1	Proper intended use.....	15
2.3.2	Operating conditions.....	15
2.3.3	Improper use.....	15
2.4	Mechanical residual hazards.....	17
2.4.1	Fins, sharp unit corners and edges.....	17
2.4.2	Fans.....	17
2.5	Electrical residual hazards.....	18
2.6	Thermal residual hazards.....	18

2.6.1	Danger of burns.....	18
2.7	Residual hazards with CFC/HFC refrigerant/.....	18
2.8	Residual hazards caused by vibrations.....	20
2.9	Residual hazards caused by pressurised parts.....	20
2.10	Residual hazards caused by defective installation.....	21
2.11	Residual hazards with break during operation.....	22
2.12	Residual hazards caused by escaping objects or liquids.....	23
2.13	Residual hazards with disposal.....	23
3	Technical data.....	25
3.1	Unit.....	25
3.2	Fans.....	25
4	Set-up and function.....	27
5	Fan motor.....	28
6	Transportation and storage.....	29
6.1	Safety.....	29
6.2	Transportation and storage.....	29
6.3	Storage before installation.....	31
7	Set-up and start-up.....	32
7.1	Safety.....	32
7.1.1	Safety instructions for set-up and start-up.....	32
7.1.2	System-side safety requirements.....	33
7.1.3	Customer-side safety precautions.....	34
7.2	Requirements at the set-up point.....	34
7.3	Unpacking the unit.....	38
7.4	Installation.....	39
7.4.1	System-side requirements for stress-free installation.....	39
7.4.2	Mounting the unit.....	40
7.5	Notes on connecting the unit.....	40
7.5.1	Connect the unit to the system.....	41
7.5.2	Unit electrical connection and protection.....	41
7.6	Perform acceptance test.....	42
7.7	Test readiness for operation.....	43
7.8	Putting the unit into operation for the first time.....	43
8	Operation.....	45
8.1	Safety.....	45
8.2	Putting the unit into operation.....	45
8.3	Taking the unit out of operation.....	45
8.4	Shutting the unit down.....	46
8.5	Putting the unit into operation after a shutdown.....	47
8.6	Changing the unit over to another working fluid.....	47

9	Troubleshooting.....	48
9.1	Safety.....	48
9.2	Service.....	48
9.3	Troubleshooting table.....	48
10	Maintenance.....	49
10.1	Safety.....	49
10.1.1	Before starting all maintenance.....	49
10.1.2	With all maintenance work.....	49
10.1.3	After all maintenance work.....	50
10.2	Inspection and maintenance plan.....	51
10.2.1	Fans.....	51
10.2.2	Unit heat exchanger.....	51
10.3	Maintenance work.....	53
10.3.1	Remove leaks.....	53
10.4	Clean unit.....	53
10.4.1	General.....	53
10.4.2	Clean heat exchanger.....	53
10.4.3	Cleaning fans.....	55
11	Plans/diagrams.....	57
11.1	Electrics documentation.....	57
11.1.1	Fan motor connection diagram.....	57
11.2	Working fluidconnection diagram.....	57

1 Important basic information

1.1 Safety instructions

1.1.1 Observing operating instructions

CAUTION

- ▶ Always keep the operating instructions in the unit's immediate vicinity at all times.
- ▶ Ensure that the operating instructions are accessible to all people that have anything at all to do with the unit at all times.
- ▶ Ensure that the operating instructions are read and understood by all people that have anything at all to do with the unit.

1.2 Importance of the EN 378 series of standards – refrigeration systems and heat pumps – safety-related and environmental requirements

EN 378 deals with safety-related and environmental requirements for designing, constructing, producing, installing, operating, maintaining and disposing of refrigeration systems and cooling equipment.

EN 378 is oriented towards manufacturers, installers and operators of refrigeration systems and cooling equipment (see section 1.2. Responsibilities).

The objective of EN 378 is to restrict the possible hazards of refrigeration systems, cooling equipment and their working fluids (refrigerants and coolants) for people, property and the environment to a minimum.

Insufficient safety measures or non-compliance with safety-relevant regulations can result in:

- Breaks or ruptures on components with the danger of escaping materials (hazards caused by the influence of low temperatures, excess pressure, direct influence of the fluid phase, moving machine parts).
- Escaping working fluid after a break or leak because of defective design, improper operation, insufficient maintenance, repairs, filling and disposal (hazards caused by oxygen deficiency, flammability, frostbite, suffocation, panic)

1.3 Responsibilities

1.3.1 Manufacturer's responsibilities

The notes provided in these operating instructions on maintaining the unit's functional safety, preventing possible hazards when transporting, setting up and installing, start-up and operation, and with maintenance activities (cleaning, servicing and repairing) refer exclusively to the unit.

The manufacturer's responsibilities are documented in the unit's version in acc. with EN 378-2 (design, manufacture and testing).

The construction, soldering and welding materials are configured so that they withstand the foreseeable mechanical, thermal and chemical stresses, and are resistant to the working fluid and the working fluid/refrigerator oil mixture used.

The working fluid-carrying parts of the unit (core tubes, distributor tube and header outlet) are configured so that they remain tight with the foreseeable mechanical, thermal and chemical stresses, and withstand the maximum permissible operating pressure.

Material, wall thickness, tensile strength, corrosive resistance, shaping process and testing are suitable for the working fluid used and withstand the possible pressures and stresses that might occur.

All responsibilities regarding the equipment, into which the unit is integrated, are the exclusive responsibility of the people involved in the individual workflows.

1.3.2 Responsibilities of the system's installer

The responsibilities of the system installer are documented in the system's version (design, manufacture and testing – cooling equipment and refrigeration system) in acc. with EN 378-2.

Component supplier-system installer interfaces :

- Inform Guntner AG & Co. KG if faults occur:
Inform Guntner AG & Co. KG immediately if faults occur during the set-up, installation, start-up and operation.

The responsibilities of the system installer in particular include:

- Planning and preparing emergency measures:
To avoid consequential damage caused by operational disruptions, a warning system which immediately signals all faults must be provided on-site. Prepare emergency measures that prevent consequential damage for people and property should faults occur.
- Install emergency STOP switches that can be actuated without danger.
- Specify checking and maintenance intervals:
The system (complete system) must be configured and equipped with all required equipment for maintenance and sufficient servicing and testing in acc. with EN 378-4.

With the integration of the unit into the refrigeration system/ the working fluid and version must not deviate from the order-related information specified in the order-related offer documents.

The installer of the system must refer to the requirement for sufficient instruction of the operating and supervision staff when operating and maintaining the equipment .

It is recommended that the future customer staff – if possible – be present with the set-up and installation, with the tightness test and cleaning, with the filling with working fluid and with the setting of the equipment .

1.3.3 Owner or operator responsibilities

The owner or operator responsibilities are documented in the operation, maintenance, servicing and recovery of the system in acc. with EN 378-4.

The owner or operator must ensure that the proper people are sufficiently trained and qualified for operating, monitoring and servicing the system .

The operating personnel for the system must have sufficient knowledge and experience with regard to the mode of operation, operation and daily monitoring of this system .

Before the system start-up the owner or operator must ensure that the operating personnel are sufficiently instructed with the system's documentation (which is part of the operating instructions) on the set-up, monitoring, mode of operation and servicing of the system and the safety measures to be observed, and with regard to the properties and handling of the working fluid to be used.

The owner or operator must ensure that when operating, monitoring and maintaining the system the working fluid and version must not deviate from the details specified in the order-related offer documents.

Planning and preparing emergency measures: To avoid consequential damage caused by operational disruptions, a warning system must be installed on the customer's premises. Prepare emergency measures that prevent consequential damage for people and property should faults occur.

Responsibility remains with the owner or operator of the system, if the system are used by somebody else, unless there is an agreement on sharing responsibility.

1.4 Legal notes

Warranty claim expires as follows:

- With faults and damages that can be attributed to non-compliance with the specifications of these operating instructions.
- With complaints that can be attributed to use of spare parts other than the original spare parts specified in the order-related offer documents.
- With changes to the unit (working fluid, version, function, operating parameters) vis-a-vis the order-related information specified in the order-related offer documents without the manufacturer's prior consent.

The operating instructions may not be reproduced electronically or mechanically, circulated, changed passed on to third parties, translated or used otherwise, in full or in part, without Guntner AG & Co. KG's prior explicit written approval.

1.5 Operating instructions

1.5.1 Scope

These operating instructions apply for all condensers of the series GVM.

NOTICE

You will find the precise type of your unit in the attached order-related offer documents.

1.5.2 Set-up and other applicable documents

The unit's operating instructions include the following parts:

- These instructions
- Order-related offer documents
 - The order-related offer documents are attached to these instructions and include the following information:
 - The order-related proper use as specified
 - The order-related scope of delivery
 - The order-related technical data
 - The order-related drawings specifying customer, project number and order number
- Motor connection wiring diagram in terminal boxes

These operating instructions are part of the operating instructions manual of the system, provided by the system's installer.

1.6 Conventions

1.6.1 Typographical conventions

The following text markups are used in these operating instructions:

Bold	Requires special attention!
Grey triangle	Instructions

1.6.2 List of abbreviations

Abbreviations	Meaning
CFC / HFC	Alkane group refrigerant, e.g. R134a, R404A, R407C, R507, ...
EN 378	European Norm 378: Refrigeration systems and heat pumps; safety-related and environmental requirements
EN	European Norm
DIN	German industrial standard (specification of a standard)
ISO	International Standardization Organization
Emergency STOP	Switch for immediately switching off the refrigeration system
°C	Degrees Celsius (Celsius scale temperature)
bar	Unit of pressure
l	Litre (liquid volume)
Vol %	Volume percent (concentration level relative to a volume)
IP	Insulation protection
Q 6.3	Balancing quality
ppm	parts per million, concentration figure, stands for "millionth"
Hz	Hertz (frequency)
D	Delta connection (rotating current: high speed)
S	Star connection (rotating current: low speed)
3~	3-phase rotating current
1~	1-phase alternating current
VDE	"Verband der Elektrotechnik, Elektronik und Informationstechnik" (Association for Electrical, Electronic & Information Technologies)
TCC	Technical Connection Conditions
EPC	Electric Power Company
VDI	"Verein Deutscher Ingenieure" (German engineers' association)

1.7 Conventions for safety signs and notices

1.7.1 General safety signs and their meaning in these operating instructions

DANGER

Dangerous situation that will definitely cause serious injury or death if it is not avoided.

WARNING

Dangerous situation that could cause serious injury or death if it is not avoided.

CAUTION

Dangerous situation that could cause slight to moderate injury if it is not avoided.

NOTICE

Refers you to possible damage to property.

1.7.2 Warning signs and their meaning in these operating instructions



Warns against hand injuries!

Hands or fingers can be crushed, pulled in or otherwise injured with non-compliance.



Warns against hot surfaces!

The temperature is over +45 °C (protein clotting) and can cause burns.



Warns against dangerous electrical voltage!

Danger of an electric shock if voltage-carrying parts are touched.



Warns against fire-risk substances at set-up point.

Use of ignition sources can cause fire at set-up point.



Warns against harmful to health or irritant substances at set-up point

Contact with or inhaling harmful to health or irritant substances can cause injuries or damage the health.

1.7.3 Prohibitory signs and their meaning in these operating instructions



Feuer, offenes Licht und Rauchen verboten!

Ignition sources must be kept away and ignition sources must not develop!



No smoking!

Smoking is forbidden.

1.7.4 Mandatory signs and their meaning in these operating instructions.



Use eye protection!

Eye protection: Use protective cover, protective glasses or face protection.



Use hand protection!

Protective gloves must protect against mechanical and chemical dangers (see imprinted pictograms).



Use respiratory protection!

Breathing apparatus must be suitable for the working fluid used. Breathing apparatus must consist of:

- At least two independent breathing devices (self-contained breathing apparatus)



Use protective clothing!

Personal protective clothing must be suitable for the working fluid used and for low temperatures, and must have good heat insulation properties.




Activate before work!

Activate the electrical system and secure against switching on again before starting installation, maintenance and repair work.

2 Safety


2.1 Labelling on the unit:



Placing of labels on the unit

2.1.1 Safety signs on the unit

Safety signs on the unit individually:



3 - "Transportation filling" warning sign next to Schrader valve

Achtung • Caution • Attention


Ventilator-Betrieb nur mit Schutzgitter
GEFAHR!

Fan operation only with guard grille!
DANGER!

Mode opératoire de ventilateur qu'avec brille protective!
DANGER!

7 - "Guard grille" warning sign (only used with separate removable guard grille)

2.1.2 Other signs and notes on the unit



1 - Unit type plate



2 – Güntner logo



12 - Connections ON and OFF

2.2 Basic safety notices

2.2.1 How to act in an emergency

WARNING

Danger of injuries!

The CFC/HFC refrigerants that are used (R134a, R404A, R407C, R507, R22 ...) are Group L1/A1 refrigerants in compliance with classification according to flammability (L) and toxicity (A) in compliance with EU Directive 97/23/EG for pressure equipment (Pressure Equipment Directive):

- Refrigerants that, when gaseous, are non-flammable irrelevant of their concentration in air.

- Refrigerants with a time-weighted, averaged concentration that have no adverse effects on the majority of staff that are exposed every day during a normal 8 hour working day and a 40 hour working week to this concentration, which is greater than or equal to 400 ml/m³ (400 ppm (V/V)).

There is no imminent danger for the staff. However, refrigerants of the Group L1/A1 are generally heavier than air and may flow off to rooms on a lower level. In still air there may be an increase of the ground level concentration. With high concentrations there is a danger of suffering from disordered cardiac rhythm and suffocation due to a reduced oxygen concentration, especially at ground level.

Unauthorised people must not have access to the unit. Please ensure that the CFC/HFC refrigerant escaping from the unit cannot penetrate the interior of the building or put people at risk in any other way.

Safety measures and procedure:

- With unexpected serious refrigerant escapes, leave the set-up room immediately and activate the emergency STOP switch set up in a safe place, e.g. with:
 - Visibly escaping refrigerant liquid or vapour from the heat exchanger or pipe components.
 - Sudden large release (release and evaporation of the greater part of the entire refrigerant filling in a short time, e.g. in less than 5 minutes).
 - Activation of the refrigerant detector (limit value in acc. with EN 378-1; Annex E):
- Have experienced, trained personnel with prescribed protective clothing perform all necessary protective and other measures:
 - Use respiratory protection.
 - Use a room air-independent breathing apparatus with maintenance work in high refrigerant concentrations in the room air.
 - Ensure the set-up room is well ventilated in acc. with EN378-3.
 - Divert escaped refrigerant vapour and escaped refrigerant liquid safely.
 - Ensure that no refrigerant enters water systems or sewage.

2.2.2 Personnel, care requirements

CAUTION

The unit must only be put into operation, operated, maintained and repaired by trained, experienced and qualified personnel. People that are responsible for the operation, maintenance, repair and evaluation of systems and their components must have the required training and specialist knowledge for their work in acc. with EN 378-1 to be qualified. Qualified or expert means the ability to satisfactorily perform the activities required for the operation, maintenance, repair and evaluation of refrigeration systems and their components.

The unit may be operated by operating personnel that have no specific knowledge of refrigeration engineering, but have sufficient knowledge and experience with regard to the mode of operation, operation and daily monitoring of this system. This operating personnel may not make any interventions or settings on the system.

Changes to the unit, which the manufacturer has first agreed to in writing, may only be made by the instructed and qualified personnel.

Electrical installation:

Work on the electrical equipment may only be performed by personnel that have the required expertise (e.g. an electrician or an electro-technically instructed person), and who are authorised by the operator, in compliance with the respective VDE regulations (and national and international provisions) and the TCCs of the EPCs.

2.3 Proper intended use

2.3.1 Proper intended use

Condensers of the GVM series are intended for installation in a refrigeration system and for outdoor installations. The condensers condense the refrigerant by giving off heat to the air that is moved by fans over the dry heat exchanger surface.

Güntner axial condensers are designed for outdoor installation.

The unit is delivered for operation with a specific operating point:

- Condensation temperature
- Airflow volume
- Air inlet temperature
- Relative air humidity.

The specified operating point is provided in the order-related offer documents.

2.3.2 Operating conditions

The unit is a component a cooling system including its working fluid circuit. The purpose of these operating instructions, as part of the operating instructions manual (of which these operating instructions are a part), is to restrict the dangers to people and property and the environment from the unit and the working fluid used in it to a minimum. These dangers are essentially connected with the physical and chemical properties of the working fluid and with the pressures and temperatures that occur in the working fluid-carrying components of the unit [see Residual hazards with CFC/HFC refrigerant/, page 18](#).

WARNING

Danger of injuries and damage to property!

The unit must only be used in acc. with the proper intended use. The operator must ensure that when operating, monitoring and maintaining the unit, the fluid and version do not deviate from the order-related information specified in the order-specific offer documents.

The operator must ensure that maintenance measures are performed in compliance with the system's operating instructions manual.

Filling the unit is only permitted following written approval by the manufacturer. You will find the order-related proper use as intended in the order-specific offer documents.

Do not exceed the max. operating pressure given on the unit's type plate.

2.3.3 Improper use

WARNING

Danger of injuries and damage to property!

Working fluids and their combinations with water or other substances in the working fluid-carrying components have chemical and physical effects from the inside on the materials surrounding them. The unit must only be pressurised with CFC/HFC refrigerant. Pressurising the unit with another working fluid results in,

- material, wall thickness, tensile strength, corrosive resistance, shaping process and testing are not suitable for the working fluid used and do not withstand the possible pressures and stresses that might occur.
- the unit not being resistant to the other working fluid and the other working fluid mixture.
- the unit not remaining tight during operation and when shut down.
- a possible sudden escaping of working fluids could directly endanger people and/or property and the environment.

The maximum permissible operating pressure specified on the type plate must not be exceeded! If the operating pressure is exceeded,

- the structural and welding materials will not withstand the foreseeable mechanical, thermal and chemical stresses and the pressure that can occur during operation and when shut down.
- the unit will not remain tight during operation and when shut down.
- there may be a possible sudden escaping of working fluids after a break or leakage on working fluid-carrying components, which would result in the following dangers:
 - Danger of escaping materials
 - Dangers caused by oxygen displacement
 - Fire hazard (caused by refrigerator oil parts)
 - Frostbite hazard (caused by liquid coolant squirting/splashing)
 - Suffocation hazard
 - Hazards caused by panic reactions,
 - Environmental pollution

WARNING

CFC/HFC Condensers/Drycooler may not be used

- where it is possible that short or prolonged effect caused by contact, inhalation or ingestion of the working fluid might result in harmful hazards.
- where the possibility exists of a sudden large release (release and evaporation) of the greater part of the entire working fluid filling in a short time (e.g. in less than 5 minutes).

The unit must not be changed without prior written consent by Guntner AG & Co. KG. Changes to the unit are:

- Changing the operating point (see chapter [Unit](#))
- Changing the fan capacity (air volume)
- Changing the working fluid flow-through volume
- Changing over to another working fluid

The unit must not be operated if safety devices recommended by the manufacturer are not available, not properly installed or not fully functional.

The unit must not be operated if it is damaged or demonstrates faults. All damages and faults must be reported to Guntner AG & Co. KG immediately and must be removed immediately.

Work on the unit must not be performed without the personal protective equipment specified in these operating instructions.

2.4 Mechanical residual hazards

2.4.1 Fins, sharp unit corners and edges

⚠ WARNING



Warns against hand injuries!

Danger of cuts on hands and fingers on the fins and on sharp corners and edges of the unit.



Use reliable hand protection!

2.4.2 Fans

⚠ WARNING



Danger of cutting off, pulling in!

There is a danger of cutting off fingers on the rotating fan blades, injury hazard for the hands and pulling in danger for loose elements such as hair, necklaces or clothing parts.

Do not operate fans without guard grille. Pinch/trap point hazard!



With automatic fan start during maintenance work there is a danger of pinching/trapping for the hands and fingers.

Power off the unit before you begin maintenance work with which you must remove the guard grille. Secure the unit against unintentional switching on again by removing the electric fuses for the unit. Secure the unit with a suitable warning sign referring to unintentional switching on.



2.5 Electrical residual hazards

⚠ WARNING



Warns against dangerous electrical voltage!

Direct and indirect contact with voltage-carrying parts of motors and electrical lines can cause serious injuries or death.

Power off the unit before you begin maintenance work. See the refrigeration system's system documentation for this. Secure the unit against unintentional switching on again by removing the electric fuses for the unit. Secure the unit with a suitable warning sign referring to unintentional switching on.



Please note that the mains cables may also be carrying voltage, even if the unit is powered off.

Work on electrical equipment must only be performed by people that have the required expertise (e.g. an electrician or an electro-technically instructed person) and who are authorised to do so by the operator.

2.6 Thermal residual hazards

2.6.1 Danger of burns

⚠ WARNING

Warns against hot surfaces!

During electrical components the heat exchanger coil (heat exchanger) of the unit, the tubes (hot gas defrosting) and heater rods have temperatures of over +45 °C. Contact can cause burns.

With refrigerant temperatures of above +45 °C there is hazard of burns on pipe components and header inlets.

With refrigerant temperatures of above +45 °C there is hazard of burns on pipe components and header inlets.

Use hand protection!

2.7 Residual hazards with CFC/HFC refrigerant/

The CFC/HFC refrigerants that are used (R134a, R404A, R407C, R507, R22 ...) are Group L1/A1 refrigerants in compliance with classification according to flammability (L) and toxicity (A) in compliance with EU Directive 97/23/EG for pressure equipment (Pressure Equipment Directive):

- Refrigerants that, when gaseous, are non-flammable irrelevant of their concentration in air.
- Refrigerants with a time-weighted, averaged concentration that have no adverse effects on the majority of staff that are exposed every day during a normal 8 hour working day and a 40 hour working week to this concentration, which is greater than or equal to 400 ml/m³ (400 ppm (V/V)).

There is no imminent danger for the staff. With good air ventilation and removal by suction, it will fall easily and clearly below the allowed limit values.

 **WARNING**

Danger of harm to health and environmental damage!

Refrigerants of the Group L1/A1 are generally heavier than air and may flow off to rooms on a lower level. In still air there may be an increase of the ground level concentration. With high concentrations there is a danger of suffering from disordered cardiac rhythm and suffocation due to a reduced oxygen concentration, especially at ground level.

- Unauthorised people must not have access to the unit.
- Ensure working rooms are well-ventilated in order to prevent inhalation of high vapour concentrations.
- Please ensure that the CFC/HFC refrigerant escaping from the unit cannot penetrate the interior of the building or put people at risk in any other way. CFC/HFC refrigerant vapour or gas must be kept from penetrating neighbouring rooms, staircases, yards, passages or drainage systems and must be discharged without risk.
- Monitor the CFC/HFC refrigerant concentration in the ambient air to ensure constant compliance with limit values.
- Test the tightness of the unit regularly, as specified in these operating instructions ([see Inspection and maintenance plan, page 51](#)).



Ignition and fire hazard!

- With work involving fire or sparks, e.g. grinding, welding, etc., ensure suitable fire fighting equipment is on-site.
- In particular be aware of the danger of ignition of unintentionally carried in oil residues or CFC/HFC refrigerant.
- Ensure that the provided fire fighting equipment is provided in sufficient quantities, that it functions properly and that the extinguishing agent does not react with the CFC/HFC refrigerant.
- Smoke during work is forbidden!



Frostbite hazard

Splashing CFC/HFC refrigerant under defervescence can cause frostbite on the eyes and skin.

- When removing faults after CFC/HFC refrigerant spills, you must be vigilant for remaining CFC/HFC refrigerant still under defervescence.



Danger of poisoning!

CFC/HFC refrigerant contact with fire can form toxic combustion products.

- Prevent CFC/HFC refrigerant contact with open fire.
- Welding and soldering must therefore only take place after completely draining the relevant section of the system of the CFC/HFC refrigerant. Ensure good ventilation here!
- With emergency work in high refrigerant concentrations in the room air wear a room air-independent breathing apparatus.



2.8 Residual hazards caused by vibrations

WARNING

Danger of injuries and damage to property caused by escaping materials

If fans are damaged during fan operation, flying parts of the fan blades can injure people or cause damage to property close to the fan.

Fans, components and cables in the system, must be designed, constructed and integrated so that dangers caused by vibrations that it or other parts of the system generate are reduced to an absolute minimum, while incorporating all available means for reducing vibrations, preferably at the source.

NOTICE

Damage to property caused by vibrations

Vibrations that are increased by imbalances, as created by dirt or fan blade damage, are regularly caused with fan operation. The vibrations are transferred to the unit, where they can cause damage and damage the unit mounting or refrigeration system components connected to the unit.

Check the fan blades and guard grille regularly for dirt and the fans' smooth running ([see Fans, page 51](#)).

2.9 Residual hazards caused by pressurised parts

WARNING

Injury and damage to property caused by pressurised parts that contain CFC/HFC refrigerant!

Breaks in pressurised pipes or pressurised components of the unit can cause injuries or damage to property caused by escaping materials. A sudden large release of the working fluid with its hazardous properties after a break or leak on pressurised components of the unit can cause the following hazards:

- Oxygen displacement
- Flammability caused by refrigerator oil % present
- Frostbite (caused by liquid refrigerant squirting/splashing)
- Suffocation
- Panic,
- Environmental pollution

Ensure that the unit in question is pressure-free before maintenance work begins or remove the working fluid from the unit in question.

Only perform maintenance work – especially soldering work – on the unit in question after completely removing the working fluid from the unit.

2.10 Residual hazards caused by defective installation

WARNING

Injuries and damage to property caused by defective installation!

Defective installation results in hazards caused by:

- Break or leak on liquid-carrying unit components and pipes
- Absence of release devices to prevent liquid escape: Liquid that can heat up during a refrigeration system shutdown state and cause pipes or connection flanges to break when it expands must not be locked in.
- Uneven load distribution on the fixtures with the danger of stresses within the unit or unit displacement (breaks or leaks on fluid-carrying components of the unit and pipes; danger of breaking off).
- Insufficient securing of working fluid-carrying lines against mechanical damage! On-site connections: loaded installation; effect of forces on the distribution and header pipes with the danger of breaks or leaks on fluid-carrying components of the unit and pipes; danger of breaking off!
- Break-off and fall danger of the unit with hazard of escaping working fluid and exposed electrical cables.
- Danger of damage caused by environment-conditional hazard sources (production, transport and other processes at the set-up point).
- Unit functional faults caused by air inlet/outlet obstructions.
- Obstruction of all-side inspection, checks and maintenance, i.e. no unobstructed accessibility to the working fluid-carrying and electrical components, connections and cables, no recognisable identifiers on the pipes and insufficient space for tests.

Ensure that:

- The units are to be installed on the fixing points corresponding with their weights and tightened with fixing bolts. The operator or installer is responsible for ensuring that the bolted connections are of an adequate strength.
- The diameters of the mounting holes have been statically determined by the manufacturer and the fixing bolts are adapted accordingly.
- The fixing bolts are secured against loosening by means of an appropriate locking device.
- The fixing bolts are not overtightened or stripped.
- All fixing bolts are tightened equally to achieve a load distribution on the connections that is as balanced as possible.
- All fixing points maintain the same spacing to the fixing level permanently and under load, so that no mechanical stress occurs in the unit structure. The units are anchored in their fixing position in order to prevent the equipment from moving.
- The functional safety of the fixing bolts is tested as part of the maintenance periods. [see Maintenance, page 49.](#)
- The unit is fixed and set up so that it is not damaged by environment-conditional hazard sources (production, transport and other processes at the set-up point) or its functioning is not disturbed by the interventions of unauthorised persons.
- The units are fixed and set up so that unobstructed air inlet/outlet is constantly available without any air short circuiting.
- The units are fixed so that they can be inspected, checked and maintained from all sides at all times, i.e. there must be unobstructed access to the refrigerant-carrying and electrical components, connections and lines, the pipeline labelling must be identifiable and adequate space must be available for testing.

- The working fluid-carrying lines are protected against mechanical damage. On-site connections: when installing keep the unit free of load; force must not be exerted on the distribution and header pipes.
- The following must be observed without fail when installing the unit:
 - Imperative adherence to spacing from objects that could be endangered by an effect of the CFC/HFC refrigerant.
 - Provision of measures to safeguard protective objects from a CFC/HFC refrigerant concentration of more than that permissible in acc. with EN 378-3.
 - Easily flammable materials must not be placed below the unit.
 - Set up and fix units as follows: In areas that are used for inner-plant traffic, the pipelines to and from the unit must only be installed with connections and fittings that cannot be removed.
 - Release devices to prevent liquid escapes must be provided and available.
 - Under-cooled liquid must only be present in the lowest possible amount in system sections in shutdown state – minimized number of "fluid sacks".
 - That when switching over a duty pump to a reserve pump no liquid, cold refrigerant remains in the pump.

2.11 Residual hazards with break during operation

⚠ WARNING

Injuries and damage to property caused by break during operation!

- Residual hazards with break during operation ([see Residual hazards caused by defective installation, page 21](#)),
- Non-compliance with maximum permissible operating pressure ([see Operating conditions, page 15](#)),
- Disregarding pressurised line sections with maintenance ([see Residual hazards caused by pressurised parts, page 20](#)).
- Disregarding residual hazards caused by vibration ([see Residual hazards caused by vibrations, page 20](#))

result in ruptures during operation and maintenance. This results in dangers caused by

- escaping materials ([see Residual hazards caused by pressurised parts, page 20](#)).
- released working fluid ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).

Ensure that:

- The installation is fault-free.
- The maximum permissible operating pressure is always adhered to.
- Pressurised line sections are de-pressurised before all maintenance and repair work.
- Vibrations from the refrigeration system (vibrations caused by the complete system's compressors, components and lines,) and from the fan (imbalances caused by frosting, icing or dirt build-up or damages) are reduced with all available means and brought down to an absolute minimum.
- Release devices to prevent liquid escapes are provided and available.
- Under-cooled liquid is only present in the lowest possible amount in system sections in shutdown state – minimized number of "fluid sacks".

2.12 Residual hazards caused by escaping objects or liquids

WARNING

Injuries and damage to property caused by escaping objects or liquids!

Residual hazards caused by escaping objects and liquids ([see Residual hazards with break during operation, page 22](#)).

2.13 Residual hazards with disposal

WARNING

Danger of injuries and damage to property caused by CFC/HFC working fluid, , !

The following notes are recommendations for the proper professional disposal of the unit. Applicable waste disposal laws are binding for the country of operation:

- Disposal must only be carried out by experts.
- All unit components, e.g. working fluids, refrigerator oil, heat exchangers, fans must be disposed of properly as specified.
- Used working fluid that is not determined for reuse, must be treated as waste and safely disposed of. There must be no emissions into the environment.
- The CFC/HFC refrigerant must be filled into a special refrigerant container in compliance with the respective safety measures. This special refrigerant container must be suitable for the refrigerant. It must be easy to identify and labelled for the refrigerant, e.g. "HFC R-4304A recovered".
- A disposable single-use container must not be used, as refrigerant vapour residues in the container escape during disposal.
- The working fluid container must not be overfilled. The maximum permissible pressure of the working fluid container must not be exceeded during the work process.
- The working fluid must not be filled in a liquid container that contains another or an unknown working fluid. This other or unknown working fluid must not be released into the atmosphere, but rather identified, treated again, or properly disposed of as specified.
- An officially authorised facility can be used for destroying the working fluid.
- Used refrigerator oil that has been recovered from the unit and cannot be treated again, must be kept in a separate, suitable container, treated as waste and safely disposed of.
- It must be ensured that all unit components containing working fluids and refrigerator oil, are disposed of properly as specified.
- The unit consists predominantly of the basic materials, copper, aluminium, galvanized steel (heat exchangers and enclosures), steel, polyamide (motors). These materials can be handled by the waste industry, including in paint-treated state, to recycling via mechanical and thermal separation.
- Before scrapping the working fluid-carrying unit components must be drained, whereby the pressure must be reduced to at least 0.6 bar absolute for a unit pipe volume up to and including 200 l, and to 0.3 bar absolute for a unit pipe volume over 200 l. The pressure reduction process is then ended when the pressure no longer increases and remains constant, and the unit is at ambient temperature.

 **WARNING**

Danger of environmental pollution!

The facility for recovering or disposing of the refrigerant must be operated so that the danger of a refrigerant or refrigerator oil emission into the environment is kept as low as possible.

- Ensure that no working fluid enters water systems or sewage.
- Operate the facility for recovering or disposing of working fluids so that the danger of a working fluid or refrigerator oil emission into the environment is kept as low as possible.

Güntner AG & Co. KG's transportation packaging is made from environmentally compatible material and is suitable for recycling.

3 Technical data

3.1 Unit

NOTICE

The fans' capacity values depend on the ambient temperature and on the air resistance at the set-up point.

All electrical parts must be installed in acc. with EN standards.

Project number	See order-related offer documents
Unit name	See order-related offer documents
Manufacturer number	See order-related offer documents
Production year	See order-related offer documents
Working fluid	See order-related offer documents
Volume	See order-related offer documents
Permissible operating pressure	32 bar
Test pressure	35.2 bar
Permissible operating temperature	-50 ... +100 °C
Permissible air humidity	100 %
Test date	See order-related offer documents
Test medium	Dry air
Airborne noise emitted	See order-related offer documents In acc. with standard procedure for calculating sound level in acc. with EN 13487; Annex C (normative).
Weight	See order-related offer documents

3.2 Fans

Fans used for the seriesGVM are switched in alternating current 230 V 1~ 50 Hz; 230 V 1~ 60 Hz geschaltet. The fans used can be speed-controlled with Güntner control units.

Fan type	See order-related offer documents
Protection rating	IP 44 insulation class F
Current type	alternating current
Voltage	230 V 1~ 50 Hz or 230 V 1~ 60 Hz
Balancing quality	Q 6.3 in acc. with VDI 2060
Permissible air temperature	Usage range: -30 C to +55 °C

Fan type	See order-related offer documents
Protective devices	<ul style="list-style-type: none">• Thermal: Thermo contacts (break contact - protective device for preventing thermal overload).• Mechanical: Protective contact grille in acc. with EN 294

4 Set-up and function

The condenser consists of,

- a heat exchanger, consisting of tube coils fitted with fins (copper tube, aluminium fin),, distribution tubes and header outlets (copper) and tube connections to the tube system,
- The enclosure consists of galvanized sheet steel, painted.
- and – depending on the version – with one or more low noise axial fans, with maintenance-free motors. Two fan versions are possible here: normal and boosted (option).

The GVM series condensers are intended for installation in a refrigeration system. The refrigeration system is a combination of refrigerant-carrying components and fittings connected with one another, which form a closed circuit, in which the refrigerant circulates.

The refrigerant absorbs heat at a low temperature and low pressure and evaporates (evaporator-side), and at a higher temperature and higher pressure gives off the heat again and condenses itself (condenser-side). The condensers condense the refrigerant by giving off heat to the air that is moved by fans over the dry heat exchanger surface.

The CFC/HFC refrigerants used (R134a, R404A, R407C, R507, R22 ...) are Group L1/A1 refrigerants ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).

Fan motor

The fan motors are operated in 1~ alternating current (IP44). The speeds can be controlled with Guntner control units.

The motors are protected with built-in thermo contacts.

5 Fan motor

NOTICE

During longer storage or downtime periods, the fans must be operated for 2 to 4 hours each month.

NOTICE

In the case of fans with protection type IP55 or higher, any sealed condensate drain holes must be opened at least every six months.

AC technology

The AC motors are protected against overheating by a thermo-contact (or positor).

For motors with thermocontacts, the thermocontact has to be wired in the switch cabinet in such a way that turning on of the motor with triggered thermocontact is not possible. A locking device is recommended for preventing reactivation.

Motors with PTC resistors require an additional trigger device for the installed thermistors. Locking is recommended to prevent reactivation. Max. 2.5 V test voltage or current-limited meters may be used on thermistors.

When star-delta connection, corresponding time delays must be taken into consideration.

For motors with direct start and a connection value > 4.0 kW, a startup current limitation (softstart using thyristor) may be necessary.

If frequency converters for speed control are used, the following has to be observed for external rotor motors:

Between frequency converter and motor, an effective all-pole sine filter has to be installed (sine-shaped output voltage! Filter effect between phase against phase, phase against earth).

Güntner frequency converters feature this function as standard. Güntner three-phase standard motors are suitable for direct operation on frequency converters.

The three-phase fan motors can be operated by means of star-delta connection with two speeds and/or with speed control. The direction of rotation must be checked. If the direction is wrong, it can be changed by interchanging two phases.

Electronic technology

NOTICE

The fan motors avail of a separate electronic power circuit. This power circuit is controlled via Güntner Motor Management GMM. The motors can be powered at single-phase (1~, 200 - 277 V AC, 50/60 Hz) and three-phase (3~, 380 - 480 V AC, 50/60 Hz) voltages. Please refer to the wiring diagrams or motor terminal box information for the electrical connection.

6 Transportation and storage

6.1 Safety

WARNING

Crushing danger with falling down!

The unit weighs between 12 kg and 38 kg. The unit weighs between 12.5 kg and 38 kg. It can slip and fall off the means of transport, causing serious injuries or death. Heavy impacts or vibrations can damage the unit.

Observe the instructions on the transport labels on the packed units.

Ensure that the assigned staff is trained for proper unloading.

Use a transporting device appropriate for the unit's weight ([see Transportation and storage, page 29](#)). You will find the weight of the packed unit in the order-related offer documents.

Ensure that nobody is under the unit or near the loaded area during the transport.

Observe even distribution of unit weight for transport. Observe the instructions on the transport labels on the packed units ([see Other signs and notes on the unit, page 13](#)).

Secure the unit against slipping and mechanical damage.

Use auxiliary transport equipment where required. Use a transporting device appropriate for the unit's weight. You will find the weight of the unit in the order-related offer documents ([see Set-up and other applicable documents, page 7](#)). Do not use connection pieces and header pipes as hooking points for lifting, pulling, fixing or mounting. This can cause leaks.

Transport the unit carefully. Avoid setting the unit down hard in particular.


6.2 Transportation and storage

NOTICE

Read and observe all transport signs on the units' packaging!

Prolonged mechanical stresses caused by uneven road surfaces and potholes and vibrations during transport by ship can cause transportation damage. Before transportation by sea or in countries with difficult transport routes, attachment parts that are likely to vibrate – in particular fans and base stands – must be removed for transportation.


- Transporting the unit at the set-up point
- Unloading the unit



- A Wooden pallet
- B 2-3 units packed on top of each other

- Transport and unload the packed unit with suitable transport equipment (e.g. forklift, crane) at the set-up point.

CAUTION: When transporting with a forklift: Only lift the packed unit with a forklift with full fork length.



6.3 Storage before installation

NOTICE

Danger of corrosion and dirt build-up!

Moisture and dirt must be prevented from entering the unit.

- ▶ **Protect the unit against dust, dirt, moisture and wetness, damage and other harmful effects.**
Harmful effects: [see Safety instructions for set-up and start-up, page 32](#)
- ▶ **Do not store the unit for longer than necessary. Only store the units in their original packaging until installation. Always only place packaging units of the same size on top of one another.**
- ▶ Store the unit at a protected place free of dust, dirt, moisture and damage-free until its set-up (well-ventilated halls or roofed storage site).
- ▶ If the unit set-up is delayed with regard to the planned installation time: protect the unit against weather and other harmful effects and dirt and other contaminants with an appropriate cover. The unit must also be well-ventilated here.

7 Set-up and start-up

7.1 Safety

7.1.1 Safety instructions for set-up and start-up

WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant!

Incorrect installation causes the danger of working fluid escaping when the unit is operated and injuries or damage to property ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).

Follow the set-up instructions in this chapter precisely and apply extreme care!

NOTICE

Damage to the system's cooling equipment!

Foreign materials and contaminants in the working fluid circuit can impair the effectiveness or damage components. Particularly harmful contaminants are:

- Moisture
- Atmospheric air
- Soldering residues
- Rust
- Soot/ash/cinders
- Metal cuttings
- Unstable oils
- Dust and dirt of all kinds

Moisture in the working fluid-carrying components of the unit can have the following consequences:

- Water separation and ice formation cause faults in the switching and control fittings of the refrigeration system
- Acidification
- Ageing and refrigerator oil decay
- Corrosion

Atmospheric air and other non-condensable gases can have the following consequences:

- Refrigerator oil oxidation
- Chemical reactions between working fluid and refrigerator oil
- Increased condensing pressure in the system

Chemical reactions between working fluid and refrigerator oil with the absence of moisture or atmospheric air with ageing and working fluid and refrigerator oil decay can have the following consequences:

- Formation of organic and inorganic acids
- Increased compressed gas temperature in the system
- Corrosion
- Bad lubrication, increased wear and tear through to system or failure

Other contaminants can cause:

- Accelerated chemical processes (decomposition)
- Mechanical and electrical faults in the refrigeration system

Ensure with installation (connecting the working fluid-carrying components of the unit to the working fluid-carrying system of the installation's that internal contamination is strictly avoided.

Perform the installation with extreme cleanliness.

Finish all on-site pipe installation work before releasing the transport pressure!

Only release the transport pressure on the Schrader valve immediately before installation.

Only remove the sealing caps on the distribution and header pipe immediately before installation.

NOTICE

Danger of corrosion and dirt build-up!

Humidity and dirt may not get into the unit's interior. If humidity or dirt get into the unit's interior, fittings and other components of the refrigeration installation can be damaged.

Protect the unit against dust, contamination, moisture and wetness, damage and other harmful influences. Harmful influences are, for example:

- **Mechanical:** Damages caused by impacts, objects falling on or against, collisions with transport equipment, etc.
- **Physical:** Damages caused by close by concentrated flammable gases
- **Chemical:** Damages caused by contaminated atmospheres (salt, acid, chlorine, sulphur-containing, or similar)
- **Thermal:** Damages caused by close by heat sources

Start as soon as possible with installation.

⚠ WARNING

The electrical installation must only be performed by electricians in compliance with the relevant VDE rules (or applicable national and international regulations) and the TCCs of the EPCs!

7.1.2 System-side safety requirements

The unit is a component of an installation and can only be operated in conjunction with the installation

- All equipment required for operating the unit must be integrated into the switching and activation equipment :
 - Electrics: Fans
 - Working fluids: valves and fittings
- An emergency STOP switch that can be actuated without danger must be installed.
- The working fluid-side and electrical connections must be available on the system. The connections must be specified in the order-related offer documents.
- The power supply of the fans must be provided in acc. with the specifications on the type plate on the fan motors.
- A switch-off device for preventing unexpected start-up (repairs switch), which separates all active conductors from the power supply (all-pole switch-off), must be provided for the fans in acc. with EN 60204-1.
- The fans' switch-on/off device must be secured (e.g. with a padlock) to prevent uncontrolled fan start-up.
- The electrical motor, repairs switch, terminal box and switching cabinet connections must be provided in acc. with the respective connection diagrams.
- It must be possible to shut off the unit if a leak occurs.

- People wearing ambient air-independent breathing apparatus in full protective clothing must also be able to activate all safety-relevant shut-off fittings.
- It must be possible to activate all devices meant for diverting escaping working fluids from a safe position.

7.1.3 Customer-side safety precautions

WARNING



Danger of injuries!

The unit contains CFC/HFC refrigerant (see [Residual hazards with CFC/HFC refrigerant/](#), page 18).

The CFC/HFC refrigerants that are used (R134a, R404A, R407C, R507, R22 ...) are Group L1/A1 refrigerants in compliance with classification according to flammability (L) and toxicity (A) in compliance with EU Directive 97/23/EG for pressure equipment (Pressure Equipment Directive):



- Refrigerants that, when gaseous, are non-flammable irrelevant of their concentration in air.
- Refrigerants with a time-weighted, averaged concentration that have no adverse effects on the majority of staff that are exposed every day during a normal 8 hour working day and a 40 hour working week to this concentration, which is greater than or equal to 400 ml/m³ (400 ppm (V/V)).



There is no imminent danger for the staff. However, refrigerants of the Group L1/A1 are generally heavier than air and may flow off to rooms on a lower level. In still air there may be an increase of the ground level concentration. With high concentrations there is a danger of suffering from disordered cardiac rhythm and suffocation due to a reduced oxygen concentration, especially at ground level.

Unauthorised people must not have access to the unit. Please ensure that the CFC/HFC refrigerant escaping from the unit cannot penetrate the interior of the building or put people at risk in any other way.

Comply with the requirements of EN 378-3 for refrigerants, filling weight and cold transfer systems.

WARNING

Danger of environmental pollution!

- Ensure that no refrigerant enters water systems or sewage.
- Operate the facility for recovering or disposing of refrigerant so that the danger of a refrigerant or refrigerator oil emission into the environment is kept as low as possible.

7.2 Requirements at the set-up point


You will find the dimensions and weights in the order-related offer documents.

- ▶ Ensure that the unit is set up so that it is not damaged by environment-conditional hazard sources (production, transport and other processes at the set-up point) and its functioning is not disturbed by the interventions of unauthorised persons.
- ▶ Position the unit so that it cannot be damaged by internal traffic or transport processes.

- ▶ Enable optimum unit control and accessibility:
 - Place the unit so that it can be monitored and controlled from all sides at all times.
 - Ensure that sufficient space is provided for maintenance.
 - Ensure that all liquid-carrying components, connections and lines and all electrical connections and lines are easy to access.
 - Ensure that the pipes' identification is well visible.

NOTICE

Lightning antennae beside the unit are recommended as lightning protection.



1

Air direction

Condition for minimum distance for installation near to wall of a building:

Distance from wall of building:


- for single-row units: $X \geq 0,6 * H$

- for double-row units: $X \geq 0,5 * H$
- Side clearance: $Y \geq 800 \text{ mm}$

Note:

The unit's air intake may only be obstructed by a building wall on one side

7.3 Unpacking the unit




- A Wooden pallet
- B 2-3 units packed on top of each other

► Check delivery scope on completeness. For complete delivery scope, refer to the order-specific offer documents.

- ▶ Note damage due to transport and / or missing parts on the delivery note. Report damage or missing parts immediately to the manufacturer in writing. Damaged fins can be straightened with a fin comb on site.
- ▶ Check transport excess pressure: The units are delivered by the manufacturer with approx. 1 bar transport excess pressure (cleaned and dried air). Check transport pressure at the Schrader valve (pressure measurement). For pressure-less unit: Report immediately to manufacturer and note missing pressure on delivery note. Ein druckloses Gerät deutet auf eine Undichtigkeit am Gerät hin.

WARNING! Danger of injuries and damage to property due to escaping convector fluid! A pressure-less unit is sign of a leak on the unit due to transport damage. Escaping convector fluid due to leaks on the unit can lead to injuries (see [Residual hazards with CFC/HFC refrigerant/](#) page 18). Do not take the unit into operation!



- 1 Transport pressure filling
- 2 Check transport pressure; inform manufacturer with unpressurised unit
- 3 Release transport pressure
- 4 Remove blanking plugs.

NOTICE

Danger of corrosion and dirt build-up!

Moisture and dirt must be prevented from entering the unit.

Protect the unit against dust, dirt, moisture, wet conditions, damaging and other detrimental influences. Detrimental influences: [see Safety instructions for set-up and start-up, page 32](#)

Begin with the installation as soon as possible.

7.4 Installation

7.4.1 System-side requirements for stress-free installation

- ▶ Prevent stresses in the unit:
 - Ensure that all fixing points have the same spacing to the fixing level.
 - Ensure that all fixing points maintain the same spacing to the fixing level under load and permanently.
- ▶ Set up and fix units as follows: Airflow must not be impaired by obstructions.
- ▶ The units must be installed on fixing points that are appropriate for the unit's weight and then bolted with fixing bolts. The operator or installer of the equipment is responsible for ensuring that the bolted connections are of an adequate strength. The following instructions must be observed when fixing the units:
 - The diameter of the mounting holes have been statically determined by the manufacturer; the fixing bolts must be adapted accordingly. When calculating the transferring bearing

strength it is imperative to take into account the total weight of the unit (= structural weight + weight of pipe content + additional weight, such as water, frost, ice, dirt or similar).

- The fixing bolts must be secured against loosening with an appropriate locking device.
- The fixing bolts must not be overtightened or stripped.
- All fixing bolts must be tightened equally.
- ▶ Prevent the unit from shifting in its position. Fix the unit in its position. Tighten the fixing bolts and secure them against loosening.
- ▶ Only fix the unit to the intended fixing points.

7.4.2 Mounting the unit

WARNING

Danger of injuries with escaping CFC/HFC refrigerant!

In case of improper installation, leak of working fluid can occur during operation of the installation, this can lead to injuries or damage to property ([see Residual hazards with CFC/HFC refrigerant/, page 18](#))

- Only fix the unit to the fixing points intended for this.

7.5 Notes on connecting the unit

WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant!

In case of improper installation, leak of working fluid can occur during operation of the installation, this can lead to injuries or damage to property ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).

Prevent working fluid from escaping from the unit into the environment.

- Secure all working fluid-carrying lines against mechanical damage.
- In areas that are used for internal traffic, only lay the pipelines to and from the unit with connections and fittings that cannot be removed.

Ensure that the on-site connections do not exercise any forces upon the distribution and header points. This can cause leaks on the working fluid connection points of the unit and on connection points of the on-site pipe-laying.

Ensure that:

- Release devices to prevent liquid escapes are provided and available.
- With refrigeration system shutdown state, under-cooled liquid is only present in the lowest possible amount in system components – minimized number of "fluid sacks".

7.5.1 Connect the unit to the system

WARNING

Danger of injuries and damage to property!


Improper connection to the system causes hazards:

- Leaks result in escaping CFC/HFC refrigerant ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).
 - Soldering and welding work on pressurised parts can result in fires or explosions.
 - Smoking or open light can cause fires due to the presence of refrigerator oil.
 - Ensure that stresses and vibrations from the system are not passed on to the unit.
 - Only lay working fluid-side connections stress-free! The on-site pipeline system must be braced before connecting to the unit!
 - Soldering and welding work is only permitted on unpressurised units!
 - Evacuate the unit professionally in acc. with EN 378-2.
 - The use of open fire at the installation site is forbidden. Fire extinguishers and extinguishing agents used to protect the equipment and the operating staff must comply with the requirements of EN 378-3.
 - Ensure that refrigerant detectors and alarm systems for warning about fire dangers, about health-endangering concentrations and for control purposes at the unit set-up point are arranged in acc. with EN 378-3; section 7.
- Install the pipes in acc. with EN 378-1 and EN 378-3. Ensure here:
- Release devices to prevent liquid escapes must be provided and available.
 - That in shutdown state under-cooled liquid is only present in the lowest possible amount in system sections – minimized number of "fluid sacks".
 - That the pipeline installation is kept as short as possible. Use as few bends as possible, and if bends are necessary, use big radii!
 - The condensate drain pipe must run with a slight slope of 3–5°.
 - Liquid and pressure lines must always run apart and must be insulated on both sides
 - Electrical components, e.g. for fan operation, for ventilation, for illumination and for alarm system on installation site, have to be designed with regard to condensation of air humidity and droplet formation in acc. with EN 378-3; section 6.

7.5.2 Unit electrical connection and protection

The fans can be speed-controlled with the use of Güntner control units.

- Connect fan motors in acc. with motor connection circuit and check connection.
- Provide power supply in acc. with the specifications on the fan motor's type plate:
 - The fan motors are operated in 1 ~ alternating current (IP 44)
- Connect thermo contacts for motor protection.



- 1 Defrost limit sensor position (if used)
- 2 Electrics (fan motor, stamp data, connection values)

- ▶ Seal all electrical lines to the connection boxes in acc. with their protection class. The connection class is specified in the order-related offer documents.
- ▶ **NOTE! Danger of damaging! If the fusing is too high there is the danger of injuries to people and damage to property. The supply lines must always be fused in acc. with the smallest wire cross-section.**

7.6 Perform acceptance test

⚠ WARNING

Danger of injuries and damage to property!

Escaping CFC/HFC refrigerant can cause injuries or even death ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).

Perform the following acceptance test with an expert before starting up the unit after making important changes and after a unit swap-out.

- ▶ Ensure that sufficient air can be sucked in and released.
- ▶ Ensure that the supply feed is sufficient for the required energy. Compare the unit inside of the system with the plans of the system and the electrical wiring diagrams.
- ▶ Test the unit for vibrations and movements that can be caused by the fans and operation of the system. Remove oscillations, vibrations and movements following consultation with the manufacturer or independently.
- ▶ Perform visual inspection of the structural design, the brackets and fixtures (materials, sequence, connections), the ability to operate and the arrangement of the fittings.
- ▶ Check and re-tighten all threaded connections, especially on the fans.
- ▶ Check installation of pipe connections.
- ▶ Check laying of working fluid-carrying connection pipes.
- ▶ Ensure that the unit is protected against mechanical damage.
- ▶ Ensure that the unit is protected against inadmissible heating up and cooling down.
- ▶ Check the fin blades protection.

- ▶ Ensure that optimum unit control and accessibility are guaranteed.
 - Is the unit placed so that it can be monitored and controlled from all sides at all times?
 - Is sufficient space provided for maintenance?
 - Are all liquid-carrying components, connections and lines and all electrical connections and lines easy to access?
 - Are the pipes easy to identify?
- ▶ Check heat exchanger surfaces for dirt and clean as required ([see Clean unit, page 53](#)).
- ▶ Perform function tests on the fans (rotation direction, power consumption, etc.).
- ▶ Check electrical connections of the fan motors for damage.
- ▶ Check the quality of the soldering connections, the electrical connections and the fixture connections.
- ▶ Perform pressure test with test gas and with a test pressure of 1.1-times the permissible operating pressure: check the connection seals and detect leaks, e.g. with foaming agent, or similar.
- ▶ Check corrosion protection: Perform a visual inspection on all bends, components and component holders that are not heat-insulated. Document and archive test results.
- ▶ Perform test run. Observe and check unit during test run, in particular for:
 - Fan smooth running (bearing noises, contact noises, imbalances, etc.).
 - Fan power consumption:
 - Leaks
- ▶ Report all defects to the manufacturer immediately. Remove defects following consultation with the manufacturer.
- ▶ Check the unit and the unit's interaction with of the system again after 48 operating hours, especially on the connections and on the fans, and document the test results.

7.7 Test readiness for operation

- ▶ Ensure that all electrical protective measures are ready to function.
- ▶ Ensure that all working fluid-carrying connections are securely in place.
- ▶ Ensure that all electrical connections (fans) are effected securely.
- ▶ Ensure that all threaded connections on the fans, the unit fixing bolts and all other threaded connections are firmly tightened.

7.8 Putting the unit into operation for the first time

⚠ WARNING

Danger of injuries and damage to property!

Escaping CFC/HFC refrigerant can cause injuries or even death ([see Residual hazards with CFC/HFC refrigerant/, page 18](#)).

Only put the unit into operation, when:

- the units has been properly mounted and connected ([see Installation, page 39](#)),
- You have performed a complete acceptance test ([see Perform acceptance test, page 42](#)).
- You have performed a test for ensuring the system's readiness for operation ([see Test readiness for operation, page 43](#)) and

- all safety precautions ([see Safety, page 32](#)) have been taken.

Follow the operating instructions manual of the system!

Contact the manufacturer immediately if you want to operate the unit under different operating conditions as those defined in the order-related offer documents.

- ▶ Switch on the system including of the electrical system (see system).
- ▶ Activate the unit:
 - Open the valves on the inlet and outlet-side system.
 - Activate fans
- ▶ Wait until the operating point is reached. After the operating point is reach the unit is ready to operate (see system).

Parameters for setting the operating point, see order-related offer documents. Operating point:

- Condensation temperature
- Airflow volume
- Air inlet temperature

To ensure the specified operating point is complied with the actuators for the operating point setting must be secured against unauthorized access (e.g. by sealing, screwing on caps, removing hand wheels, etc.).

8 Operation

8.1 Safety

WARNING

Danger of cutting off, pulling in!



There is a danger of cutting off fingers on the rotating fan blades, injury hazard for the hands and pulling in danger with loose elements such as hair, necklaces or clothing parts.

Do not operate fans without guard grille!

WARNING

Burn hazard!



Danger of burns if parts are touched ([see Thermal residual hazards, page 18](#)).

Do not touch any parts of the unit without protective gloves when the unit is in operation or if it has not yet cooled down again after operation.



8.2 Putting the unit into operation

To operate the unit, the refrigeration system must be in operation, including the electrical system. The unit must be started up by opening the respective valves on the inlet and outlet-side of the refrigeration system, by connecting to the electrical system as follows (see refrigeration system operating instructions manual):

- ▶ Switch on electrical system
- ▶ Open working fluid-carrying lines
- ▶ Switch on fans

8.3 Taking the unit out of operation

The units are system components of a refrigerating system. The unit is taken out of operation by switching off the refrigeration system in acc. with the refrigeration system operating instructions manual. To do this, the working fluid-carrying lines must be shut off from the refrigeration system and the fans must be switched off by the electrical system (see refrigeration system operating instructions manual):

- ▶ Switch fans off
- ▶ Switch electrical system off
- ▶ Close working fluid-carrying lines
- ▶ **NOTE!** When shut down consider max. operating pressure! If necessary, take precautions so that it cannot be exceeded.

NOTICE

With shutdown times of a month or longer put the fans into operation for approx. 2-4 hours a month to maintain their functionality.

8.4 Shutting the unit down

⚠ WARNING

Danger of injuries and damage to property!

Escaping CFC/HFC refrigerant can cause injuries ([see Residual hazards with CFC/HFC refrigerant/, page 18](#), and [see Residual hazards caused by pressurised parts, page 20](#)).

Ensure that the maximum operating pressure is not exceeded after the shutdown either!

NOTICE

Danger of corrosion and dirt build-up!

Moisture and dirt must be prevented from entering the unit.

Protect the unit against dust, dirt, moisture, wet conditions, damaging and other detrimental influences ([see Safety instructions for set-up and start-up, page 32](#)).

With shutdown times of a month or longer put the fans into operation for approx. 2-4 hours a month to maintain their functionality.

- ▶ Take the unit out of operation ([see Taking the unit out of operation, page 45](#)).
- ▶ Secure the unit:
 - When shutdown consider max. operating pressure ([see Technical data, page 25](#))! If necessary, take precautions so that it cannot be exceeded.
 - Secure the fan motor drives against switching on again
 - Secure working fluid-carrying lines against pressurizing with working fluid.
 - Secure unit against detrimental influences at the installation or storage location ([see Safety instructions for set-up and start-up, page 32](#)) in order to keep all unit components in good state for proper use and to conserve the usability of the unit. For this purpose, special storage conditions ([see Storage before installation, page 31](#)) and preventive measures for corrosion protection have to be provided, regular testing of the functionality of the fans and of the unit taken out of operation have to be effected.
- ▶ Evacuate the unit: Completely release working fluid and, if applicable, refrigerator oil ([see Residual hazards with disposal, page 23](#)).

8.5 Putting the unit into operation after a shutdown

The unit must be put back into operation after a shutdown in acc. with the system-specific set-up in acc. with the operating instructions manual as follows:

- ▶ Test the unit's readiness for operation (see [Test readiness for operation, page 43](#)). Perform pressure test and visual inspection for corrosion protection.

NOTE! The pressure test with recommissioning must only be carried out with appropriate media at appropriate test pressure.

- ▶ Put the unit into operation (see [Putting the unit into operation, page 45](#)).

8.6 Changing the unit over to another working fluid

WARNING

Danger of injuries and damage to property!

Considerable dangers can be caused with operation with another working fluid without prior manufacturer approval ([Improper use](#)).

The unit must not be changed over to another working fluid without prior written consent by Guntner AG & Co. KG.

- ▶ Ensure that the unit manufacturer has agreed to the changeover.
- ▶ Ensure that the right working fluid is re-filled. Ensure that all materials used in the unit are compatible with the new working fluid.
- ▶ Ensure that the permissible pressure is not exceeded.
- ▶ Check that the new working fluid can be used without requiring a new test certificate for the unit. Ensure that classification is complied with.
- ▶ The safety device for the unit must be swapped out or reset.
- ▶ Mixtures with residues of working fluid and oil, for example, must be prevented.
- ▶ All information concerning the new working fluid must be changed accordingly.
- ▶ The complete documentation, including these operating instructions and the system operating instructions manual must be changed accordingly.
- ▶ Perform acceptance test (see [Perform acceptance test, page 42](#)).

9 Troubleshooting

9.1 Safety

⚠ WARNING

Danger of injuries and damage to property!

Faults that are not described in these operating instructions must only be removed by Guntner. Contact the Guntner hotline.

Faults that are described in these operating instructions must only be removed by appropriately trained personnel ([see Personnel, care requirements, page 14](#)).

With faults that occur during the operation, monitoring and maintenance of the complete system, inform Guntner AG & Co. KG immediately.

9.2 Service

Office hours

Tel. +49 8141 242-473

Fax. +49 8141 242-422

Email: service@guentner.de

Mon-Thurs: 7.30 am - 5 pm

Fri: 7.30 am - 1.30 pm

9.3 Troubleshooting table

Fault	Possible cause(s)	Remedy
Fan motor not running	Power supply interrupted	Restore power supply
	Fan blade stuck	Enable fan to rotate freely
Bearing noises	Defective fan motor	Renew bearing or fan motor
Unit vibrating	Defective fan blades	Change fan blades
	Loose fan fixture	Tighten fixtures
Unit capacity not achieved	Coil is strongly contaminated with dirt	Clean
	Fans not running properly or down	Repair, swap out fans
	Working fluid pressurising defective (temperature and quantity insufficient)	Set working fluid pressurising values (temperature and quantity) to reference values.
Working fluid escaping	Unit working fluid-carrying components leaking	Switch off working fluid feed and fans, close leak

10 Maintenance

10.1 Safety

10.1.1 Before starting all maintenance

WARNING

Danger of injuries and damage to property with escaping working fluid ([see Residual hazards with CFC/HFC refrigerant/, page 18](#))!

Only perform maintenance work – especially welding work – on the leaking unit after completely removing the working fluid from the leaking unit!

Perform the following safety measures before beginning all maintenance work:

- drain the unit's heat exchanger
- Clean and blow out the unit's heat exchanger.

10.1.2 With all maintenance work

WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant!

Escaping refrigerant with leaks on the evaporator can cause the following hazard situations and injuries:



Warning against explosion-risk and fire-risk substances in the set-up room!
Unintentionally carried in oil residues can ignite.

- Ensure that there is no unintentionally carried in oil in the set-up room .
- Keep the risk area free of direct and indirect ignition sources.
- Before releasing for maintenance obtain the required approvals for work for the unit that can involve ignition sources (e.g. grinding, welding, soldering, etc.).
- With all work involving ignition sources (e.g. grinding, welding, soldering, etc.) in the work area, keep suitable fire extinguishing equipment that meets the requirements of EN 378-3 at hand.
- Do no bring any open flames or hot gases (e.g. candles, matches, welding beads, welding sparks, glowing cinders or tobacco) into the set-up room.
- Ensure that there are no warmed up or hot surfaces (e.g. heaters, hotplates, bulbs, motor housings) in the set-up room.
- Ensure that no frictional heat develops in the set-up room (e.g. overheated stores).



Warns against health-endangering irritants in the set-up room!

CFC/HFC refrigerant under defervescence still present can evaporate. Inhalation of refrigerant vapour causes harmful to health irritations and lack of oxygen.

- Escaping refrigerant vapour and escaping refrigerant liquid must not reach adjacent rooms, staircases, yards, passages or drainage systems.
- Use respiratory protection.

- Use a room air-independent breathing apparatus with maintenance work in high CFC/HFC refrigerant concentrations in the room air.
- Ensure the set-up room is well ventilated.
- Divert escaped refrigerant vapour and escaped refrigerant liquid safely.



Warns against cold!

Still present CFC/HFC refrigerant under defervescence has a temperature of 0 °C. Contact with refrigerant under defervescence caused by spraying causes frostbite.



- Use eye protection!



- Use hand protection!

- Ensure that the unit in question is pressure-free before maintenance work begins or the working fluid is sucked up from the unit in question.
- Power off the electrical system and secure it against unintentional switching on again.
- Separate the unit to be maintained from the refrigeration system and secure it.

NOTICE



Danger of damage to property!

With work in the inlet and outlet feeds of the fans and heat exchanger, objects can get into the fans and therefore cause faults and damage on the components.

- Power off the fans before beginning maintenance work and secure them against switching on again.
- After the work has finished do not allow any objects to get back into the inlet and outlet feeds of the fans or the set-up room.

10.1.3 After all maintenance work

WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant! [see Residual hazards with CFC/HFC refrigerant/, page 18](#)!

Perform the following safety measures after finishing all maintenance work:

- Ensure the switching and activation devices, the measuring and display devices and the safety devices function properly.
- Ensure the working fluid fittings are functioning.
- Ensure that the swivel fan units (optional) and the hinged side covers are fixed in their original position and secured against unintentional or unauthorised opening.

- Check the identification of the pipelines and ensure this is visible and legible.
- Check the fixing and corrosion protection of the components in question.
- Ensure the electrical connections (fans) are functioning.
- Ensure the temperature and air humidity at the set-up point are the same as that in the order-related offer documents.
- Perform a pressure test and a tightness test (see operating instructions manual annex).
- Perform an acceptance test ([see Perform acceptance test, page 42](#)).
- Perform a pressure test (see operating instructions manual annex).

10.2 Inspection and maintenance plan

The checks to be performed are listed in the following sections as time-scaled checklists.

10.2.1 Fans

The manufacturer's operating specifications take priority for this component. Güntner AG & Co KG recommends proceeding in acc. with the following inspection and maintenance plan:

d = daily, w = weekly, m = monthly, y = yearly				
Work to be performed	d	w	m	y
Check the fans for dirt build-ups. • With dirt build-ups: Clean fans (see Clean unit, page 53)	X			
Check the fan drive for smooth running. • Vibrations on the unit: remove imbalances • Where required, tighten and correct blade fixtures and blade settings		X		
Fan bearing: Running sound and smoothness changes • Swap out bearing			X	
Fan motor: Is a new bearing due? • Swap out bearing or motor; where applicable, clean and repair motor				X *
Fan wheel: corrosion on bolts (with threaded blades) • Swap out bolts				X *
Fan blades: Corrosion or damage on blades • Swap out blades or wheel				X *

*) Recommended: every six months

10.2.2 Unit heat exchanger

WARNING

Danger of injuries or damage to property caused by escaping CFC/HFC refrigerant ([see Residual hazards with CFC/HFC refrigerant/, page 18](#))!

d = daily, w = weekly, m = monthly, y = yearly				
Work to be performed	d	w	m	y
Check heat exchanger for dirt build-ups. • With dirt build-ups: Clean heat exchanger (see Clean unit, page 53).	X			
Check heat exchanger's general condition. • Damages found: remove damages		X		
Check heat exchanger's operating point (see Operation, page 45). • Change in fan capacity found: restore required system-side conditions . • Change in surface temperatures found: restore required system-side conditions .			X	
Check heat exchanger and connections for tightness. • Repair affected unit part (see Remove leaks, page 53).				X *
Check heat exchanger for working fluid pressurising. • Restore required system-side conditions.				X
Check heat exchanger for corrosion. • Corrosion or damage on core tubes, fins, support structures, tube connections, fixtures: repair unit sections affected.				X *

*) recommended: every six months

Care and maintenance plan

Measure	Cleaning agent	Interval
Component cleaning	Mechanically	As required (visual inspection)
Complete cleaning	Warm water or environmentally safe cleaning agent	After 120 hours After 720 hours
Leak check		After 6 months
Corrosion protection check		After 6 months

10.3 Maintenance work

10.3.1 Remove leaks

WARNING

Danger of injuries and damage to property with CFC/HFC refrigerant ([see Residual hazards with CFC/HFC refrigerant/, page 18](#))!

- Have leaks removed as quickly as possible by an expert.
 - Do not fill with a working fluid other than that specified in acc. with the order-related offer documents!
 - Only put the unit back into operation when all leaks have been repaired.
- ▶ Perform all work including pressure, acceptance and functional test ([see Perform acceptance test, page 42](#), and [see Test readiness for operation, page 43](#)).

10.4 Clean unit

10.4.1 General

The following applies for cleaning: The operator must ensure that the cleaning agent is environmental friendly. Harmful to the environment substances, e.g. acid-forming, are forbidden.

ACHTUNG - ATTENTION - ATTENTION - ATENCIÓN

Bei der Verwendung von Reinigungsmitteln in Kühlräumen, ist auf die Korrosionsbeständigkeit der Materialien des Kühlers gegenüber dem verwendeten Reinigungsmittel zu achten!

When cleaning agents are used inside the cold room, the corrosion resistance of the cooler materials to the applied cleaning agent has to be observed!

Lors de l'utilisation des détergents dans les chambres froides, il faut observer à la résistance à la corrosion des matériaux de l'appareil qui entrent en contact direct avec les détergents.

Cuando se apliquen agentes limpiadores en los productos instalados en cámaras frías, se debe tener cuidado que no corroen los materiales usados para la construcción del producto!

- ▶ Clean casing by rinsing with warm water (approx. +25°C) and/or with environmentally friendly cleaning agents.
- ▶ Rinse thoroughly with water after using cleaning agents.
- ▶ Allow casing to dry completely.
- ▶ Check working fluid-carrying and electrical connections ([see Test readiness for operation, page 43](#)).

10.4.2 Clean heat exchanger

- ▶ Drain the unit (see system).
- ▶ Shut off the unit (see system).
- ▶ Power off the fans (see system).

- ▶ Clean the heat exchanger with one of the following procedures:
 - Cleaning with compressed air ([see Cleaning with compressed air, page 54](#)).
 - Hydraulic cleaning ([see Hydraulic cleaning, page 54](#))
 - Cleaning with brushes or brushes and compressed air ([see Cleaning with brushes or brushes and compressed air, page 55](#)).

NOTICE

Danger of damage to property!

The fins can be damaged with too high a pressure, too small a distance or a cleaning jet that hits the fins at an angle. Mechanical cleaning with hard objects (e.g. steel brushes, screw drivers, or similar) damages the heat exchanger.

- Use a pressure of max. 50 bar with hydraulic cleaning and max. 80 bar with cleaning with compressed air!
 - Maintain a minimum distance from the fins of 200 mm!
 - Always aim the jet vertically (max. ± 5 degree deviation) at the fins!
 - Do not use any hard objects when cleaning!
- ▶ Switch fans on (see system).
 - ▶ Open liquid side (see system/CO2 system operating instructions manual).
 - ▶ Open high pressure side (see operating instructions manual).

10.4.2.1 Cleaning with compressed air

- ▶ Blast heat exchanger (max. 80 bar pressure) with compressed air to remove dirt and contaminants.
- NOTE!** Hold the jet of the cleaner vertical to the fins (max. deviation of ± 5 degrees) to prevent fins from bending.

10.4.2.2 Hydraulic cleaning

⚠ WARNING



Warns against dangerous electrical voltage!

Direct and indirect contact with voltage-carrying parts of motors and electrical lines can cause serious injuries or death. Water and cleaning agents conduct electricity.

- Power off the fans for cleaning with water or steam jet and ensure them against switching on again.

NOTICE


Danger of damage to property!

Water or steam jets can damage fans, electrical lines or other components.

- Ensure that electrical connections and motors, as well as components and stored goods at the set-up point are not touched by water or steam jets. Cover these if required.
- ▶ Heavier moisture or greasy dirt must be removed with a high-pressure water jet (max. 50 bar pressure), steam pressure jet (max. 50 bar pressure), min. 200 mm distance with flat jet nozzle,

or using neutral cleaning agent where applicable, always against the airflow direction. Ensure here:

- With oily and greasy dirt it helps to add a cleaning agent to the water.
- When applying chemical agents ensure that they are not aggressive towards the unit's materials. Rinse the unit off after the treatment.
- Cleaning should be done from inside to the outside (but always opposing the dirt onset) and from top to bottom, so that the dirt can be removed without returning.
- Hold the jet of the cleaner vertical to the fins (heat exchanger – max. deviation of ± 5 degrees) to prevent fins from bending.



- ▶ Continue cleaning until all dirt has been removed.

10.4.2.3 Cleaning with brushes or brushes and compressed air

- ▶ Remove dry dust or dirt with a brush, a hand brush or with compressed air (max. 80 bar pressure, min. distance of 200 mm to the fins; against the airflow direction) or with a powerful industrial vacuum cleaner. Ensure here:
 - Use soft brushes (no steel brushes or similar)!
 - Where possible, cleaning should be from the top down. Where possible, cleaning should be from top to bottom, so that the dirt can be removed without the possibility of returning to cleaned parts. Continue cleaning until all dirt has been removed.
 - Always brush the fins lengthways – never across!

10.4.3 Cleaning fans

⚠ WARNING

Danger of cutting off, pulling in!

There is a danger of cutting off fingers on the rotating fan blades, injury hazard for the hands and pulling in danger for loose elements such as hair, necklaces or clothing parts.

- **Power off the unit before you begin maintenance work. Secure the unit against unintentional switching on again by removing the electric fuses for the unit. Secure the unit with a suitable warning sign referring to unintentional switching on.**
- **Put fans and guard grilles that were removed or opened for maintenance back into their original status without fail before you put the unit back into operation!**

Dirt build-ups on the fans and the fan guard grilles must be removed regularly, otherwise they will cause imbalances or destruction and power losses. The fan motors themselves are maintenance-free.

- ▶ Power off the unit and secure it against unintentional switching on.
- ▶ Clean fans with one of the following procedures:
 - NOTE! Danger of damage to property! Mechanical cleaning with hard objects (e.g. steel brushes, screw drivers, or similar) damages the fan. Forbidden!**
 - Cleaning with compressed air: Blow fans with compressed air (max. 10 bar pressure; min. distance 200 mm) to remove dirt and contaminants. Continue cleaning until all dirt has been removed.
 - Cleaning with compressed air and brushes: Remove dry dust or dirt with a brush, a hand brush or with compressed air (max. 10 bar pressure, min. distance of 200 mm) or with a powerful industrial vacuum cleaner. Ensure here: use soft brushes (no steel brushes or similar)! Continue cleaning until all dirt has been removed.
- ▶ Mount guard grille, streamer or air inlet connections (if installed)
- ▶ Switch unit on

11 Plans/diagrams

11.1 Electrics documentation

11.1.1 Fan motor connection diagram

See motor terminal box cover inside on the fan.

11.2 Working fluidconnection diagram

See order-related offer documents